




WOOD TREATMENT SYSTEM (WTS-NS) USER'S MANUAL

Safety Precautions

- Do not connect unit to external air or gas source; use only supplied compressor.
- Do not pressurize an empty tank.
- Release air at relief valve before removing cap from tank top.
- Do not transport the unit while tank is pressurized.
- Do not treat voids with electrical outlets or cables.
- Always use a grounded (3 terminal) extension cord.
- Quick-connection between the compressor and regular can become hot to touch.




Operation



Liquid - Secure application hose to the LIQUID quick connect.

Foam - Secure application hose to the FOAM quick connect.




Before Starting



- Secure all hose connections.
- Lock the 30-L valve.
- Tighten (snug) tank cap.
- Be certain the tank is clean.

Pressure Adjustment

- Adjust the operating pressure between 50 and 70 PSIG.
- Turn clockwise to increase pressure and counter clockwise to decrease pressure.



Operating Instructions


Mixing and Filling

- To ensure adequate air pressure in tank, add only 3 gal. liquid to tank.
- Make sure switch on compressor is in the Off position, and unit is unplugged from wall connection.
- When mixing insecticides in the tank, use the gallon and liter marks on the side.
- Mix all insecticides according to label directions.
- Foaming agent must be added to tank to make foam


Pressurizing the Tank

- Connect unit to electric outlet with 3 terminal electric cord.
- Start compressor by depressing the on/off switch.
- Compressor maintains pressure in the tank, it will automatically cycle on and off during normal use.


Application Tips




1) Applying *foam* or *liquid* to narrow spaces, voids



2) Applying *foam* to large voids, surfaces
3) Injecting liquid into structural wood



4) Applying foam to large and small wall voids, and beneath a concrete slab



Care and Maintenance

- Flush tank, Gunjet valve, and extension with clean water regularly.

Part Numbers

#	Order #	Description
1	24040120	Compressor, 110V
	24040220	Compressor, 220V
2	24040059	Cart
	24040102	Cart, handle
3	24040064	Tank, 3 gallon
4	22067312	30-L Gunjet, valve
5	24040068	Hose, 30 ft.
	24040087	Hose, 50 ft.
6	24040122	Regulator, pressure
7	24040106	Check valve
8	24040069	Straight tip assembly
9	24040072	Dual tip assembly
10	24040073	90 degree void tip



Trouble Shooting

Problem: Tank not holding pressure

- Solution:**
- Tighten tank cap
 - Check for gasket in tank cap, replace if missing

Problem: Tank not getting air pressure

- Solution:**
- Inspect hose on compressor and quick connection
 - Adjust regulator knob on pressure gauge

Problem: Applying only air not foam

- Solution:**
- Tank empty, add liquid insecticide
 - Siphon tube for foam port is plugged or damaged

Problem: Foam not thick or like water

- Solution:**
- Adjust tank pressure as required
 - Clean inside of hose from tank to Gunjet valve

B&G Help Line
800-544-8811



135 REGION SOUTH DRIVE • JACKSON, GA 30233
Toll Free 800-544-8811 • Phone 678-688-5601
www.bgequip.com • Fax 678-688-5633